





VII.Screw and Nut list

NO	picture	Specification	Total quantity	Position
1		screw(M4x12)	68	set
2		screw (M4x10)	21	set
3		screw (M3x5)	26	set
4		screw(M8x88)	4	Knock down machine Step 7 Semi-assemble machine Step 4
5		screw (M5x20)	8	set
6		screw (M5x20)	8	set
7		screw (M5)	4	set
8		screw(M8x16)	4	Knock down machine Step 7 Semi-assemble machine Step 4
9		screw (M6x55)	1	set
10		screw (M6x48)	14 12	Knock down machine Step 3.5.6 Semi-assemble machine Step 2
11		screw (M6x26)	20 14	Knock down machine Step 5.6 Semi-assemble machine Step 2.3
12		screw (M6x16)	16	set
13		screw (M5x15)	4	Knock down machine Step 2
14		screw (M4x15)	4	set
15		screw (M4x12)	58	set
16		screw (M4x8)	8	set
17		screw (M3x12)	2	set



NO	picture	Specification	Total quantity	Position
18		screw (M3x10)	1	set
19		nut(M8)	16	Knock down machine Step 4.7
			12	Semi-assemble machine Step 1.4
20		nut (M6)	38	Knock down machine Step 3.5.6.11
			20	Semi-assemble machine Step 2.3.8
21		nut (M5)	4	Knock down machine Step 2
22		nut (M4)	20	set
23		nut (M6)	4	set
24		nut (M5)	8	set
25		nut (M4)	44	set
26		nut (M3)	7	set
27		sleeve (φ 15x43)	4	Knock down machine Step 7
				Semi-assemble machine Step 4
28		screw (M5x38)	4	Knock down machine Step 9
				Semi-assemble machine Step 6
29		washer(M4x12)	4	Knock down machine Step 9
				Semi-assemble machine Step 6
30		washer (M6.5x13.5)	24	Knock down machine Step 6.7
			12	Semi-assemble machine Step 3.4
31		Hexagonal Phillips screw with 2 Washers	4	Knock down machine Step 7
				Semi-assemble machine Step 4
32		screw (M4x10)	48	Knock down machine Step 1
33		screw (M8x70)	8	Knock down machine Step 3.4
			4	Semi-assemble machine Step 1


VII. Expanded view




Use PART#S
Below ↓

Item	Name	Part Number	Quantity
1	Basket acrylic board (RoHS)	1121-13800801	1
2	Basket board	2246-13800501	1
3	Main wooden board	1134-13801701	1
4	I/O control board B3 (RoHS)	2213-13800101	1
5	Running display board (RoHS)	2212-13800201	1
6	3 Digitals display board (RoHS)	2212-13800401	2
7	2 Digitals display board (RoHS)	2212-13800301	1

1121-13800801
561-50-103
561-00-140
561-00-101
561-00-102
561-00-103
561-00-104



Item	Name	Part Number	Quantity
1	Frame for main wooden board fix use	1132-13800601	1
2	Basket upper back cover (AVR type)	1134-13801801	1
3	Basket lower back cover	1134-13802401	1
4	Light back cover	1134-13801401	1
5	Light T5 14W	0963-18000011	1
6	Light reflection board	1134-13801501	1




USE PART #S
BELOW ↓

Item	Name	Part Number	Quantity
1	Wooden board for basket unit fix use	1134-13801101	1
2	Bearing (RoHS)	1151-13800301	10
3	Bearing (6002ZZ)	1243-13800101	10
4	Ball holder sensor 1.1 (RoHS)	2213-13800301	1
5	Sliding railway for sensor	1134-13802901	1
6	Bearing D type	1151-13800101	1
7	Sliding railway for basket	1134-13801601	2
8	Bearing cover	1132-13802601	2
9	Basket motor holder	1132-13801101	1
10	Basket holder	1134-13810101	1
11	Basket left holder	1132-13802701	1
12	Basket right holder	1132-13802701	1
13	Connecting rod for basket unit	1134-13801001	1
14	Gear motor (KGB-215-6130B1)	0912-00001061	2
15	Basket position bard	1134-13803001	1

OPTO SENSOR HARNESS
- 38 -

561-00-140
561-00-119
561-00-134
561-00-118
561-00-121
561-00-122
561-00-123
561-00-124
561-00-125
561-00-126
561-00-127
561-00-141
561-00-128
561-00-113
561-00-129
561-00-109



Use PART #'S
Below


Item	Name	Part Number	Quantity
1	Basket net set	1134-13800741	1
2	3M reflection sticker	1032-13800941	1
3	Basket sensor (WO-RNPW2) (RoHS)	0955-13800001	2
4	Basket sensor holder	1134-13810091	1
5	Basket sensor railway	1134-13801201	1
6	Bearing (6002ZZ)	1243-13800101	2
7	Bearing (RoHS)	1151-13800301	2
8	Basket track holder	1134-13810081	1

(only on ST.) ↗

561-50-105
561-00-130
561-00-131
561-00-135
561-00-132
561-00-134
561-00-133

STREET BASKET BALL
BALL NET HOLDER
Sensor wire ext
Sensor wire ext ext

ST-BALL
561-50-104
561-00-005
561-10-006



Use The PART#S
Below ✓


Item	Name	Part Number	Quantity
1	Main box base	1134-13800301	1
2	Link PCB (RoHS)	2215-13800201	1
3	Play button	2243-13800101	1
4	Single main PCB (RoHS)	2211-13800101	1
5	Play button	2243-13800201	1
6	Bill machine (AE2400)		1
7	Main case acrylic board (RoHS)	1121-13800701	1
8	Main case	1112-13800101	1
9	Wheel A002 without brake (RoHS)	1155-00010111	4
10	3 in 1 Name	1134-19310125	1
11	Speaker box	2246-13800401	1
12	Speaker (PL-T70130R) (RoHS)	1294-00000202	1
13	Speaker (10" RoHS)	0931-10000015	1
14	Fuse (R3-11 20mm)	0974-00001001	1
15	3P power with light (RS-003D)	0944-00000141	1
16	Push on (Red) (PB-003A)	0944-00000091	2
17	PIN counter (7 number)	0922-00001081	2
18	Counter Power Block	1134-13800101	1
19	Hole type cover	1121-13800201	1
20	Wave filter (YGD3T5)	0924-00000101	1
21	Speaker cover	1121-13800301	1
22	Transformer	0923-10000031	1
23	TICKET DISPENSOR DOOR (COVER)	1121-13803501	1
24	TICKET DISPENSOR DOOR (WITH HOLE)	1121-13803601	1

561-00-142

561-00-107

TRANSFORMER 220V/110V
TRANSFORMER 110V/15V
COIN DISPLAY B.D.
CABLE FOR LINK SUB B.D
Power Supply

561-20-109
561-20-110
561-00-137
561-00-145
561-20-112



Use The Part #s
Below

Item	Name	Part Number	Quantity
1	Wooden board – B type	2246-13800201	1
2	Board of ball stopper unit	1134-13800801	1
3	Ball stopper board unit	1134-13800901	1
4	Hook for basket (650X46.6)	1134-13803301	1
5	Gear motor (KGB-215-6130 B1)	0912-00001061	1
6	Motor frisked for ball stopper unit	1132-13800901	1
7	Ball holder bearing	1151-13800201	1
8	Ball holder bearing D type	1134-13804201	1
9	Arm of ball stopper	1134-13802501	1
10	Sensor SW	2213-13800301	1
11	Bearing LF-1040	1243-13800301	2
12	Ball holder sensor holder Bracket	1132-13803001	1

561-00-112
561-00-113

561-00-116
561-00-115
561-00-117
561-00-118
561-00-119
561-00-120

1) (The right machine)



2) (Left machine)



1032-13800205	Label (DINO).....
1032-13800305	Label (STREET BASKETBALL).....

3)





1032-13800515	Play Instruction:
1023-13800205	Label for 1P Play Push Button...
1023-13800105	Label for TEAM Play Push Button...

4)



1032-13800105 Label for Wooden Board

5)



1032-13800805 Label of Left-Side Ball Guide...

1032-13800705 Label of Right-Side Ball Guide....

6)



1032-13800415 Label for Main Part Door (STREET BASKETBALL)----